


A tenant's guide to Mixer showers

Quick-start guide

Turn the Flow Control Lever anticlockwise to the preset maximum flow



Turn the Temperature Control Lever clockwise to decrease the temperature and anticlockwise to the preset maximum temperature

Always check the temperature of the shower is safe before getting in and take extra care when altering the heat while standing in the water flow.

Seasonal changes

The temperature of the cold mains water supply is generally colder during the winter months. This means the temperature dial may need to be set higher (or the “High” setting selected) in winter to meet your desired heat.

Cleaning the shower

You need to isolate the power to the shower before cleaning. The showerhead and hose should be kept clean and free from blockage to ensure the shower works correctly. Use a soft cloth to wipe away any limescale from the nozzles on the headset. Please be careful as many households cleaning product can damage plastics.

IMPORTANT - Please be aware that it is important not to carry out any unauthorised alterations to shower units, including replacing the head and hose sets. This will void the warranty and may cause the shower to fail.